NOTES: 1.) DO NOT SCALE DRAWING ASSEMBLY INSTRUCTIONS 1. ASSEMBLE GUARD ON SCRATCH-FREE SURFACE 2. ATTACH BRACKET (ITEM 5) TO WRAPPER (ITEM 3) WITH TWO RIVETS 3. ATTACH BRACKET (ITEM 5) TO SCREEN INSERT (ITEM 4) WITH TWO RIVETS 4. ATTACH TWO HANDLES (ITEM 6) TO COVER (ITEM 2) WITH LOCK TOOTH WASHERS AND 8-32 SCREWS - DO NOT USE SCREWS ENCLOSED WITH HANDLES 5. ATTACH WRAPPER WITH BRACKET TO COVER (ITEM 2) WITH 27 RIVETS 6. ATTACH SCREEN INSERT WITH BRACKET TO COVER (ITEM 2) WITH 17 RIVETS 7. FASTEN GUARD FRONT ASSEMBLY TO BACK (ITEM 1) WITH TWELVE 5/16 SELF-TAPPING SCREWS 8. PLACE LABEL AND DECALS (ITEMS 10, 11 AND 12) ON GUARD FRONT ASSEMBLY (10)(11)(12) GUARD FRONT ASSEMBLY

INSTALLATION INSTRUCTIONS

- 1. REMOVE ALL DRIVE SIDE BELTS AND SHEAVES FROM MILL
- 2. REMOVE 5/16 BOLTS FROM GUARD
- 3. REMOVE GUARD FRONT FROM BACK
- 4. CENTER GUARD BACK ON ROLL JOURNALS
- 5. LEVEL AND LOCATE FLOOR MOUNTING HOLES FOR BACK
- 6. DRILL FLOOR MOUNTING HOLES FOR BACK: USE 1/2 ANCHOR BOLTS

K009810

RELEASE

4/25/95 SPLIT BACK INTO 3 PCS

2/13/95

- 7. REASSEMBLE BELTS AND SHEAVES ON MILL
- 8. FASTEN GUARD FRONT TO BACK WITH 5/16 BOLTS
- 9. LOCATE AND DRILL FLOOR MOUNTING HOLES FOR FRONT: USE 1/2 ANCHOR BOLTS

13	F83200011	48	RIVET-POP SDS64 . 188 X . 125250
12	80008509	1	LABEL - DANGER
11	80003643	1	DECAL - WARNING BELT AND CHAIN
10	80003568	1	DECAL - DANGER
9	66622200	4	∯8 LOCK TOOTH WSHR
8	65683812	12	5/16-12x1/2 HX WSH HD T/C SCW
7	65482212	4	8-32x1/2 HX SLT HD T/C MCH SCW
6	K910-01232	2	HANDLE W/ HARDWARE
5	K200-02765	2	BRACKET, DR GD-18*
4	K200-02764	1	SCREEN INSERT, DR GD-18"
3	K200-02763	1	WPR, DR GD-18*
2	K200-02732	1	COVER, DIFF GD, 24"
1	K200-02730	1	BACK, DIFF, 24" LH
ITEM	PART NO.	QTY	DESCRIPTION
Tolerances EXCEPT AS			

ASSY, DIFF GD, 24" LH

2/13/95 D K100-01558

BCARR, NONE BRANK BY. M. ZEEDYK